MXI/501

Fig.8.

PA6/507 — FLYING LEADS — CAMERA CABLES — CT3/4

FADER CONTROL ASSY. 'A'

SKT1A

ILP41

ILP42

MR92 CG80H

ZCY/2

CY-1

ZA-2

FADER 'A' HOLD COILS

AM/2

MR94 CG80H

FADER CONTROL 'A' 30 PZ/9Q/1S

ZA-1

CL-1

30 WIPE CONTROL

CO/2

MR97 CG80H

CN/2

MR86 CG80H

FADER CONTROL ASSY. 'B'

SKT1B

WIPE CONTROL 30

CL-2

ZB-1

FADER CONTROL 'B' 30 PZ/9Q/1S

BM/2

MR95 CG80H

FADER 'B' HOLD COILS

ILP44

ILP43

CZ-1

ZB-2

MR93 CG80H

ZDY/2

TAG BLOCK

AM1/504 No1

AT3/501

SKT3 PL2

SKT11 PLA

FADER CONTROL CIRCUIT

UN3/502

SKT7 PLA

SKT9 PLC

SKT8 PLB

SKT1 PL2

SKT11 PLA

FADER CONTROL CIRCUIT

AM1/504 No2

AT3/501

A2Y-1

MR20 OA202

AE/2

MR55 CG80H

R1 100

C1 0·1

AIY/2

AIZ/2

AIZ-2

C2 50

R2 1k

BIZ-1

BIY-2

24-VOLT SUPPLY A

+ 24-VOLT SUPPLY B

AIZ-1

AIY-1

BE/2

MR56 CG80H

C3 0·1

R3 100

BIY/2

BIZ/2

B2Y-1

MR40 OA202

B1Z-2

R4 1k

C4 50

MXI/501/2

O.B. MIXER MXI/501 : FADER CONTROL CIRCUITS

FADER CONTROL CIRCUITS